

Item number: 1452318

Instruction manual

LED light chain

McShine „BOTTLE“

20 LEDs, approx 2 m, battery operated

NE



TECHNICAL DATA

Power supply:	3×AG13 button cells (incl.)
Light color:	warmwhite
Length:	approx 2 m

Bottle NOT included

Item number: 1452318

EN



DISPOSAL INSTRUCTIONS

By separating materials, recycling and disposing of old equipment in this way, you are making an important contribution to protecting our environment.

Packaging can be disposed of free of charge at the appropriate collection points:

- Paper in the paper bin
- Plastics in the yellow bag
- Glass in the used glass container

WEEE disposal note

According to the European WEEE Directive, electrical and electronic WEEE Directive, electrical and electronic equipment must not be disposed of with household waste.

Their components must be recycled or disposed of separately, because toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly.

As a consumer, you are obliged under the Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic equipment free of charge at the end of its service life to the manufacturer, the point of sale or to public collection points set up for this purpose.

Details are regulated by the respective state law.

The symbol of the wheeled garbage can on the product, the operating instructions and/or the packaging refers to these regulations. regulations.

Battery disposal note

Batteries and rechargeable batteries must not be disposed of with household waste. Every consumer is required by law to take all batteries and rechargeable batteries, whether they contain harmful substances or not, to a collection point in his or her community/district or to a retailer so that they can be disposed of in an environmentally friendly manner. Please return batteries and rechargeable batteries only when discharged.

SAFETY INSTRUCTIONS

- Before commissioning, check the device for damage. If this is the case, please do not put the device into operation.
- Please note that technical modifications to the device the approval of the device expires immediately!
- Keep the operating instructions of the device.
- Avoid installing the unit in places with high temperature differences or high humidity.
- Do not carelessly leave the packaging material lying around, Plastic foils/ bags, polystyrene parts, etc., could become a dangerous toy for children.
- The device does not belong in children's hands, it is not a child's toy!

SAFETY INSTRUCTIONS BATTERIES

- No attempt should be made to reactivate batteries/battery packs by heating or similar measures.
- Do not immerse batteries/accumulators in water and do not store them in a damp place, but store in a dry and cool place.
- Do not dispose of batteries/accumulators in fire, do not open them weld or solder them yourself.
- Do not short-circuit batteries/accumulators.

GENERAL NOTES

- Use only original parts supplied
- The product has no replaceable parts.
- Do not attempt to open or repair the product.

INTENDED USE

- The product is a decorative item.
- The product may only be used for the intended purpose, in accordance with these operating instructions!
- The product is not suitable for room illumination.

OPERATION

- Unwrap the string of lights.
- Insert the LEDs by the wire into the desired empty vessel.
- Insert the plastic cork into the vessel opening, without much mechanical pressure.
- Use the switch on the cork to turn the string of lights on and off.

CARE INSTRUCTIONS

- Do not use damaged light chain.
- Avoid mechanical pressure.