

Item number: 1452997

## Instruction manual

# LED socket light einlicht „Halo“

3,3 W, 438 lm, step-dimmable, warmwhite



### TECHNICAL DATA

Operating voltage:	230 V
Light color:	warmwhite
Color temperature:	3000 K
Absorbed power:	3,3 W
Lifetime:	30000 h
Illumination technology:	LED
Outer diameter:	75 mm
Height:	475 mm
Energy efficiency class:	G
Dimmable:	3 step dimming
Swiveling	flexible swiveling through gooseneck

### DISPOSAL INSTRUCTIONS

By separating materials, recycling and disposing of old equipment in this way, you are making an important contribution to protecting our environment.

Packaging can be disposed of free of charge at the appropriate collection points:

- Paper in the paper bin
- Plastics in the yellow bag
- Glass in the used glass container

### WEEE disposal note

According to the European WEEE Directive, electrical and electronic WEEE Directive, electrical and electronic equipment must not be disposed of with household waste. Their components must be recycled or disposed of separately, because toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly.

As a consumer, you are obliged under the Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic equipment free of charge at the end of its service life to the manufacturer, the point of sale or to public collection points set up for this purpose.

Details are regulated by the respective state law.

The symbol of the wheeled garbage can on the product, the operating instructions and/or the packaging refers to these regulations.

### PRODUCT DESCRIPTION

LED gooseneck light for easy mounting in a socket. The built-in bulb provides a wide-beam clear light. The socket light is dimmable in 3 steps (step-dimmable) and thanks to 36 cm flexible gooseneck flexible use. The dimmable lamp can be easily switched ON and OFF or dimmed via the switch on the base. Ideal as a reading lamp and bedside lamp by the bed or sofa. Suitable as a lamp for the work surface in the kitchen, office or workshop.

### MOUNTING INSTRUCTIONS

For connection, plug the socket light into the socket.

Bend the gooseneck to the desired position.

The lamp is switched on by pressing the power switch on the lamp base.

By touching the symbol, you can dim the lamp to different levels in different steps.

The dimmer switches between 100%, 70% and 30% brightness. This also applies to each startprocess. The light always starts at 100% the first time it is switched on.

When disconnected from the power supply, it remembers the last brightness setting. As soon as the power supply is power is restored, the lamp lights up at the last brightness level set.