

Item number: 1453148

EN

Instruction manual

LED-Outdoor spotlight

McShine „Slim“

50 W, 4250 lm, IP66, 3000K



TECHNICAL DATA

Operating Voltage:	220 – 240 V
Light color:	warmwhite
Color temperature:	3000 K
absorbed power:	50 W
Illumination technology:	LED
Length:	160 mm
Height:	209 mm
Energy efficiency class:	This product contains a light source of Energy efficiency class F

SAFETY INSTRUCTIONS

- Before commissioning, check the device for damage. If this is the case, please do not put the device into operation.
- Please note that the approval of the device immediately if technical modifications are made to the device!
- Keep the operating instructions of the device.
- When working on 230 V, please observe strict compliance with the accident prevention regulations.
- Do not short-circuit the connections and the circuits.
- Installation may only be carried out by qualified personnel.
- Please do not look directly into the light source in order to avoid injury to the eye.
- Do not carelessly leave the packaging material lying around, Plastic foils/ bags, polystyrene parts, etc., could become a dangerous toy for children.
- The device does not belong in the hands of children, it is not a toy!

OPERATING INSTRUCTIONS

- Before installation, make sure that the power is turned off.
- Choose the position of the lamp.
- Drill the screws into the position for the lamp according to the lamp frame.
- Fasten the lamp with the grub screw.
- If the position of the lamp is higher than 3 m, please use another set screw.
- Please connect the power cord of the products to the power cord by following the rule:
L to L, N to N, green-yellow to green-yellow.
- Note that the input voltage must be the same as the voltage indicated on the nameplate.
- Make sure that everything is properly connected, and then turn on the power.