

McShine "LR-9" LED Renovation Light

11W, 1100lm, 4000K, 19cm Kabel und Lüsterklemme

TECHNICAL DETAILS: · 11W · 1100 Lumen · 4000K · 19cm Kabel mit Lüsterklemme

SAFETY INSTRUCTIONS: Keep the device's operating manual. Regularly inspect the device for damage. Do not modify the product or accessories. Do not insert objects into connection sockets. The product is not suitable for outdoor use. Do not short-circuit the connections. Only use the product if it is in perfect condition. Do not operate a defective device under any circumstances! The device must not be altered in any way. Risk of electric shock and accidents! Keep the device away from moisture and humidity. Avoid extreme conditions such as excessive heat or cold, moisture, microwaves, mechanical pressure, and vibrations. Avoid overloading the renovation socket. Overloaded sockets can lead to overheating and fire hazards. Disconnect the power supply before making any connections. **Electrical work, installation, and repairs should only be carried out by qualified electricians. Avoid inserting metallic objects or fingers into the socket and connections to prevent short circuits or electric shocks - LIFE-THREATENING!** Wipe the device only with a soft, dry cloth. Do not use scouring powders or chemical cleaning agents. Electrical components must not come into contact with moisture. Do not bend, crush, pinch, or otherwise damage the cables. For questions, defects, mechanical damage, and other issues, please contact the retailer or manufacturer. If you have doubts about the safety of the renovation socket or if it does not function properly, have it inspected and, if necessary, repaired by a qualified electrician. The product is not a toy and should be kept out of children's hands! Please note that the product, as well as packaging, plastic films/bags, styrofoam parts, etc., small parts, and insulation materials can become dangerous toys for children and pose a hazard.

ASSEMBLY

1. Switch off the circuit breaker and check for power disconnection. **2.** Strip about 10 mm of insulation from the wire ends. **3.** The connections are labeled „L“ and „N“. **5.** Insert the wires into the terminals as follows: brown/black wire into „L“; blue wire into „N“; the green-yellow wire must be insulated. Make sure that no wires are clamped incorrectly or protrude. **6.** Attach the strain relief to the ceiling using a hook to avoid stressing the power supply cable. **7.** Switch on the circuit breaker and check functionality.



DISPOSAL INSTRUCTIONS: By separating, recycling and disposing of old appliances in this way, you are making an important contribution to protecting our environment. Packaging can be disposed of free of charge in accordance with local regulations at the appropriate collection centres. According to the European WEEE Directive, electrical and electronic appliances may not be disposed of with household waste. Their components must be recycled or disposed of separately, as toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly. As a consumer, you are obliged under the German Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic equipment free of charge at the end of its life to the manufacturer, the point of sale or to public collection centres set up for this purpose. Details are regulated by the respective state law. The wheeled bin symbol on the product, operating instructions and/or packaging indicates these regulations.



DE: Eine mehrsprachige Version dieser Anleitung und die Konformitätserklärung finden Sie unter folgendem Link:

EN: A multilingual version of this manual and the Declaration of Conformity can be found at the following link:

FR: Vous trouverez une version multilingue de ce manuel et la déclaration de conformité sur le lien suivant:

ES: Encontrará una versión multilingüe de estas instrucciones y de la declaración de conformidad en el siguiente enlace:

<http://ettgroup.de/product/1453636>