

Item number: 1530456

Instruction manual

Smoke Detector

McPower „KD-133A“

NE




TECHNICAL DATA

Operating Voltage:	9 V (battery-powered)
Operating Temperature:	-10° C to +40° C
Alarm Volume:	85 dB
Low Voltage Warning:	from 7,3 V
Ambient Air Humidity:	maximum 95% RH
Certified:	DIN EN 14604
Diameter:	103,36 mm
Height:	32,86 mm
Drill Distance:	70,00 mm
Continuous Monitoring:	Yes

INSTALLATION

- Detach the mounting plate from the smoke detector by rotating the detector.
- Mark the holes for attachment at a distance of 7 cm at the corresponding spot on the ceiling. You can use the mounting plate for assistance.
- Drill the holes for attachment into the ceiling using suitable tools.
- Attach the mounting plate with appropriate dowels and screws.
- Insert the 9 V battery.
- Mount the smoke detector back onto the mounting frame by rotating it.
- Press the test button. The red control LED will blink rapidly, and an audible signal will sound, ensuring the proper functioning of the smoke detector.



BATTERY REPLACEMENT

- The detector automatically detects when the battery operating voltage drops below 7.3 V.
- The detector then emits an alarm to indicate that the battery needs replacement.

DECLARATION OF PERFORMANCE (DOP)

Downloadable at:

<http://ettgroup.de/product/1530456>


SAFETY INSTRUCTIONS

- Check the device for damage before putting it into operation. If this is the case, please do not operate the device.
- Note that any technical modification to the device will immediately invalidate its approval.
- Keep the user manual for the device.
- When drilling, protect your eyes with safety goggles.
- Wearing gloves is prohibited during drilling; the glove could become entangled in the rotating drill.
- Do not expose the device to extreme temperatures, direct sunlight, or excessive humidity.
- Do not drop the device. It could be damaged upon impact on a hard surface.
- Avoid installation in places with significant temperature differences or high humidity.
- Before operating the device, ensure sufficient warm-up time. Otherwise, moisture could accumulate in the device (in case of significant temperature fluctuations).
- Do not leave packaging materials lying around; plastic films/bags, Styrofoam parts, etc., could become a dangerous toy for children.
- The device is not intended for children; it is not a toy.
- Test the alarm weekly and after battery replacement.

BATTERY SAFETY INSTRUCTIONS

- Do not attempt to reactivate batteries/accumulators through heating or similar measures.
- Do not immerse batteries/accumulators in water, and store them in a dry and cool place, not a humid one.
- Do not throw batteries/accumulators into the fire, open, weld, or solder them.
- Do not short-circuit batteries/accumulators.

DISPOSAL INSTRUCTIONS

By separating materials, recycling and disposing of old equipment in this way, you are making an important contribution to protecting our environment.

Packaging can be disposed of free of charge at the appropriate collection points:

- Paper in the paper bin
- Plastics in the yellow bag
- Glass in the used glass container

WEEE disposal note

According to the European WEEE Directive, electrical and electronic WEEE Directive, electrical and electronic equipment must not be disposed of with household waste. Their components must be recycled or disposed of separately, because toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly.

As a consumer, you are obliged under the Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic equipment free of charge at the end of its service life to the manufacturer, the point of sale or to public collection points set up for this purpose.

Details are regulated by the respective state law.

The symbol of the wheeled garbage can on the product, the operating instructions and/or the packaging refers to these regulations.

Battery disposal note

Batteries and rechargeable batteries must not be disposed of with household waste. Every consumer is required by law to take all batteries and rechargeable batteries, whether they contain harmful substances or not, to a collection point in his or her community/district or to a retailer so that they can be disposed of in an environmentally friendly manner. Please return batteries and rechargeable batteries only when discharged.



DE: Eine mehrsprachige Version dieser Anleitung und die Konformitätserklärung finden Sie unter folgendem Link:

EN: A multilingual version of this manual and the Declaration of Conformity can be found at the following link:

FR: Vous trouverez une version multilingue de ce manuel et la déclaration de conformité sur le lien suivant:

ES: Encontrará una versión multilingüe de estas instrucciones y de la declaración de conformidad en el siguiente enlace:

<http://ettgroup.de/product/1530456>