



Surface-mounted socket McPower "Finery"


4-way, 250V~/16A. plug-in protection

TECHNICAL DETAILS:
• Surface-mounted socket outlet with earthing contact
• 250V/16A
• with plug-in protection / shutter
• 4-way, Dimensions: 138x60x50mm

SAFETY INSTRUCTIONS: Keep the operating instructions for the appliance in a safe place. Check the appliance regularly for damage. Do not modify the product or accessories. Do not insert any objects into connection sockets. The product is not suitable for outdoor use. Do not short-circuit the connections. Only use the product if it is in perfect condition. Never operate a defective device! The appliance must not be modified in any way. Risk of electric shock and accident! Avoid extreme loads such as extreme heat or cold, moisture, microwaves, mechanical pressure and vibrations. Avoid overloading the socket : Do not connect several high-current devices at the same time. Overloaded sockets can lead to overheating and a fire hazard. Disconnect the mains power supply before connecting. Electrical work, installation and repairs may only be carried out by qualified electricians. Avoid inserting metal objects or fingers into the socket to prevent a short circuit or electric shock. DANCER TO LIFE! Only wipe the appliance with a soft, dry cloth. Never use scouring powder or chemical cleaning agents. Electrical components must not come into contact with moisture. Do not kink, crush, pinch or otherwise damage the cables. If you have any questions, defects, mechanical damage or other problems, please contact the dealer or manufacturer. If you have any questions to to a toy and does not belong in the hands of children! Please note that the product, packaging, plastic film / bags, polystyrene parts, etc. are not suitable for children. Small parts and insulating material can become a dangerous toy for children and pose a hazard.

ASSEMBLY

1. switch off the fuse and check that there is no voltage. 2. remove the front cover by losening the screws 3. secure the housing at the intended location using suitable screws 4. prepare the housing by making openings for the cable entry at the designated points and deburring them 5. strip the cable properly and insulate the wire ends by approx. 10 mm. 6. connect the cable as shown in the drawing. Make sure that no wires are incorrectly clamped and that no strands protrude or stick out. 7. place the housing on the assembled electrical system and ensure that the cables are correctly positioned in the housing. 8. then refit the fort cover and hand-tighten the screw.



DISPOSAL INSTRUCTIONS: By separating, recycling and disposing of old appliances in this way, you are making an important contribution to protecting our environment. Packaging can be disposed of free of charge in accordance with local regulations at the appropriate collection centres. According to the European WEEE Directive, electrical and electronic appliances may not be disposed of with household waste. Their components must be recycled or disposed of separately, as toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly. As a consumer, you are obliged under the German Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic tip prope. Details are regulated by the respective state law. The wheeled bin symbol on the product, operating instructions and/or packaging indicates these regulations.



DE: Eine mehrsprachige Version dieser Anleitung und die Konformitätserklärung finden Sie unter folgendem Link: EN: A multilingual version of this manual and the Declaration of Conformity can be found at the following link: FR: Vous trouverez une version multilingue de ce manuel et la déclaration de conformité sur le lien suivant: ES: Encontrará una versión multilingue de estas instrucciones y de la declaración de conformidad en el siguiente enlace:

CEE

http://ettgroup.de/product/1530722

Status: 11/2024