


PULSE I CONNECTION GUIDE

MAC



THRONMAX

1



1. Plug Microphone to PC from USB port
Пожалуйста, подключите микрофон к USB-порту компьютера.
Schließen Sie das Mikrofon über den USB-Anschluss an den PC an.
Koppla in Mikrofonen i datorn via USB-porten.
请将麦克风的USB接口与电脑连接

	Sound Direction	Light Mode	Recording Applications
Cardioid		Blue Led ON	STREAMING, PODCASTING, GAMING, INSTRUMENTS
Active Noise Cancellation		Blue Led Heart Beat	STREAMING, PODCASTING, GAMING

2

1. Super cardioid grille design
- Периовидная сетка, изготовленная для работы в кардиоидном режиме
- Supernierenförmige Richtcharakteristik
- Superkardioidmikrofon med gallerdesign
- 超心形格栅设计
2. Volume control scroll wheel
- Регулятор громкости
- Lautstärkenregelung über Scrollrad
- 滚轮音量按钮


3. Long press Mute & Press change mode
- Нажмите и удерживайте в течение 3 секунд, чтобы отключить звук.
- Öppnarknappat i takt - perikloppning av modus.
- Drücken zur Modusumschaltung.
- Skifta inspelningsläge, håll inne 3 sekunder för Mute
- 静音, 心形和ENC降噪模式切换按钮

4. 3.5mm audio jack
- 3.5 mm разъем для наушников
- 3.5 mm Audio-Buchse
- 3.5 mm ljudanslutning
- 3.5 mm 耳机输出接口

5. 360 Degree rotation module
- блок вращения на 360 градусов
- 360 Grad Stativ
- 360-graders rotationsmodul
- 360度旋转云台

6. Special tripod design with universal mounting screw for microphone boom arm
- Конструкция-трипод с универсальным креплением для микрофона
- Spezielles Stativdesign mit universeller Befestigungsschraube für Mikrofonstativ
- Stativ med universalskriv för mikrofonarm
- 三角支架带通用接口, 支持标准麦克风支架与防震架的螺纹底座

3



There are 2 modes comes with Pulse Microphone
Blue Light Cardioid Mode: Suitable for YouTubers, Voice recording, Instrument recording
Blue Light Heartbeat Environmental Noise Cancelling (ENC): suitable for streamers and for gamers
Red Lights: Press 3 seconds for Mute

Thronmax Pulse имеет 2 режима работы:
Кардиоидный режим: данный режим подходит для записи блогов, трансляций, записи голоса или инструментов (световой индикатор горит синим, не мигает)
Режим шумоподавления окружающей среды (ENC): данный режим подходит для стримеров и геймеров (световой индикатор мигает синим)
Для отключения звука нажмите и удерживайте соответствующую кнопку (3) в течение 3 секунд (световой индикатор загорится красным).

Das Thronmax Pulse Mikrofon verfügt über zwei unterschiedliche Charakteristiken:
Nierenförmig (blaue LED leuchtet): Geeignet für YouTuber, Sprachaufzeichnung, Instrumentenaufzeichnung
Umgebungsgeschwindigkeit (ENC) (blaue LED pulsiert): Geeignet für Streamer und Gamer
Stummschaltung: Rote LED


Thronmax Pulse har två lägen + Mute
Blått ljus, Kardioidläge (riktad): lämpligt för YouTubers, röstinspelning och instrumentinspelning
Blått ljus med hjärtslag, brusreducering: lämpligt för streamers och gamers
Rött ljus: Håll inne 3 sekunder för Mute

PULSE 麦克风有两组模式
蓝色灯常亮指示心形模式: 适用于直播, 播客, 录音, 乐器
蓝色呼吸灯指示ENC降噪模式: 适用于直播, 游戏
红色灯: 长按三秒静音

4

2. Once plug microphone windows recognize automatically. If not, you can set from control panel/sound.
Микрофон автоматически распознается вашим устройством. В случае если микрофон не обнаружен, выберите его в настройках в разделе «Звук» в качестве устройства ввода.
Sobald das Mikrofon angeschlossen ist, wird es von Windows automatisch erkannt. Wenn nicht, können Sie dies über das Bedienfeld / Sound einstellen.
Windows känner igen mikrofonen automatiskt. Om inte, kan du ställa in den från kontrollpanelen / ljud.


电脑可以自动识别麦克风并连接, 如果不成功, 可以从电脑的声音控制里面去重新设置。选择我们的麦克风设备名称Thronmax Pulse



5

3. Set microphone sensitivity from control panel/sound.
Отрегулируйте уровень чувствительности в меню настроек входа.
Einstellen der Mikrofonempfindlichkeit über das Bedienfeld/Sound.
Ställ in mikrofonens känslighet från kontrollpanelen / ljud.


从控制面板里面设置麦克风灵敏度



6

4. Set microphone sensitivity from control panel/sound.
Отрегулируйте уровень чувствительности в меню настроек входа.
Einstellen der Mikrofonempfindlichkeit über das Bedienfeld/Sound.
Ställ in mikrofonens känslighet från kontrollpanelen / ljud.


从控制面板声音里面设置耳机音量



7

5. Set microphone sensitivity from control panel/sound.
Отрегулируйте уровень чувствительности в меню настроек входа.
Einstellen der Mikrofonempfindlichkeit über das Bedienfeld/Sound.
Ställ in mikrofonens känslighet från kontrollpanelen / ljud.


从控制面板声音里面设置耳机音量



8

6. Set microphone sensitivity from control panel/sound.
Отрегулируйте уровень чувствительности в меню настроек входа.
Einstellen der Mikrofonempfindlichkeit über das Bedienfeld/Sound.
Ställ in mikrofonens känslighet från kontrollpanelen / ljud.


从控制面板声音里面设置耳机音量



9

7. Set microphone sensitivity from control panel/sound.
Отрегулируйте уровень чувствительности в меню настроек входа.
Einstellen der Mikrofonempfindlichkeit über das Bedienfeld/Sound.
Ställ in mikrofonens känslighet från kontrollpanelen / ljud.

从控制面板声音里面设置耳机音量



Disclaimer

THRONMAX reserves the final explanation of THRONMAX professional steaming microphone product, any third party applies device related information without THRONMAX's authorization is not allowed, we will take legal action. In any case, THRONMAX Ltd. is not responsible for any consequences caused by improper use of consumers.

Warranty Card

1. Warranty period:
12 months beginning on the date of purchase.
2. For the duration of the Warranty Period, THRONMAX warrants the Product against defects in materials and workmanship arising from Normal Use of the Product.
3. During the warranty period, if any of the followings occurs, certain maintenance costs will be charged:

- Product damage due to fire, flood, abnormal voltage or other natural disasters.
- The malfunction and damage caused by incorrect use, the unauthorized repairs and alteration.
- Not able to present warranty card and purchase receipt.

- The user information on warranty card is not recorded clearly or correctly.
- Product malfunction caused by the fall and improper transportation after purchase.
- Product damage caused by disassembling and repairing by user without being checked by maintenance staff from authorized store.
- The warranty card is missing the full name, purchase date, product model no., and serial no., or texts have been changed.

4. Whether or not during the warranty period, if any of the followings occurs, no maintenance provided:

- Color fading, wearing after using under proper use is not covered by warranty terms.
- If product model no. and serial no. filled in warranty card is not consistent with official product model no. and serial no, it is not covered by warranty terms.

5. Notice:

- This warranty card cannot be reissued in any case, please keep it properly and present it when repairing.
- If you have any question regarding after-sale service, please contact us or the retailer.

Address: Thronmax
4 Floor No.1 Building China&Israel High-Tech park Huanhu road
NO.7 Songshan Lake Dongguang, Guangdong,523808 China