EN:

Item number: 1535987

MC POWER

Socket outlet with protective contact McPower “FLAIR”

Orientation light, plug-in connection, anthracite

TECHNICAL DETAILS: · Flush-mounted protective contact socket with plug-in connection · 250V~/16A · LED orientation light with light sensor · Switching threshold adjustable 10–300 lux · Light output 35 lumens · Light colour: warm white – 3000 K · With child protection / shutter · Includes frame · Dimensions (WxHxD): 80x80x40mm · Suitable for hollow wall boxes with a 68mm diameter

SAFETY INSTRUCTIONS: Keep the operating instructions for the appliance in a safe place. Check the appliance regularly for damage. Do not modify the product or accessories. Do not insert any objects into connection sockets. The product is not suitable for outdoor use. Do not short-circuit the connections. Only use the product if it is in perfect condition. Never operate a defective device! The appliance must not be modified in any way. Risk of electric shock and accident! Keep the appliance away from moisture and humidity. Avoid extreme loads such as extreme heat or cold, moisture, microwaves, mechanical pressure and vibrations. Avoid overloading the socket by not connecting several high-current devices at the same time. Overloaded sockets can lead to overheating and a fire hazard. **Disconnect the mains power supply before connecting. Electrical work, installation and repairs may only be carried out by qualified electricians. Avoid inserting metal objects or fingers into the socket to prevent a short circuit or electric shock – DANGER TO LIFE!** Only wipe the appliance with a soft, dry cloth. Never use scouring powder or chemical cleaning agents. Electrical components must not come into contact with moisture. Do not kink, crush, pinch or otherwise damage the cables. If you have any questions, defects, mechanical damage or other problems, please contact the dealer or manufacturer. If you have any doubts about the safety of the socket or if it is not working properly, have it checked by a qualified electrician and repaired if necessary. The product is not a toy and does not belong in the hands of children! Please note that the product, packaging, plastic film / bags, polystyrene parts, etc. are not suitable for children. Small parts and insulating material can become a dangerous toy for children and pose a hazard.

ASSEMBLY

1. Switch off the fuse and check that there is no voltage. **2.** Strip approx. 14 mm of insulation from the wire ends. **3.** Loosen the screw in the centre and remove the cover. **4.** The plug-in terminals are labelled “L”, “N” and “E” (protective earth). **5.** Push the wires into the plug-in terminals as far as they will go: brown/black wire into “L”, blue wire into “N”, green/yellow wire into “E”. Pull gently on each wire to check that it is held firmly, and make sure that no bare wire ends protrude. **6.** Insert the socket insert into the flush-mounted box and screw the fixing claws tight. **7.** Fit the frame. **8.** Insert the cover into the frame and screw it hand-tight using the screw in the centre.

ORIENTATION LIGHT: The LED orientation light is controlled by the light sensor at the bottom left of the cover: it switches on automatically when it gets dark and off again when it gets light. The switching threshold can be set between 10 and 300 lux. To do this, turn the regulator on the back of the cover (marked “+”) with a small screwdriver: anticlockwise – the light only switches on in darker surroundings; clockwise – the light already switches on in brighter surroundings. Only make this adjustment with the fuse switched off. Do not cover the sensor.



DISPOSAL INSTRUCTIONS: By separating, recycling and disposing of old appliances in this way, you are making an important contribution to protecting our environment. Packaging can be disposed of free of charge in accordance with local regulations at the appropriate collection centres. According to the European WEEE Directive, electrical and electronic appliances may not be disposed of with household waste. Their components must be recycled or disposed of separately, as toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly. As a consumer, you are obliged under the German Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic equipment free of charge at the end of its life to the manufacturer, the point of sale or to public collection centres set up for this purpose. Details are regulated by the respective state law. The wheeled bin symbol on the product, operating instructions and/or packaging indicates these regulations.



DE: Eine mehrsprachige Version dieser Anleitung und die Konformitätserklärung finden Sie unter folgendem Link:
EN: A multilingual version of this manual and the Declaration of Conformity can be found at the following link:
FR: Vous trouverez une version multilingue de ce manuel et la déclaration de conformité sur le lien suivant:
ES: Encontrará una versión multilingüe de estas instrucciones y de la declaración de conformidad en el siguiente enlace:

http://ettgroup.de/product/1535987

Made by ETT GmbH, Schmalbachstraße 16, 38112 Braunschweig

Version: 11/2026

ett-online.de | Tel. +49 531 58 11 00 | service@ett-online.de

Reproduction or duplication only with express authorisation.