Instruction manual LED under-cabinet light McShine "SH-30"

3 W, 260 lm, 30 cm, neutral white



INSTALLATION

- Attach the mounting clips at the desired location using appropriate screws.
- The light fixture can then be carefully slid into the clips.
- Connect the light fixture to a suitable 12V power supply and check its function.

SAFETY INSTRUCTIONS

- Before using the device, check for any damage. If there is any damage, do not use the device.
- Please note that any technical modification of the device will immediately void its approval!
- Keep the user manual for the device.
- Do not look directly into the light source to avoid eye injury.
- Protect your eyes with safety glasses during drilling work!
- Wearing gloves during drilling work is prohibited! Gloves could get caught in the rotating drill.
- Do not drop the device. Impact on a hard surface could cause damage.
- Avoid installing in locations with significant temperature differences or high humidity.
- Do not leave packaging materials lying around carelessly; plastic films/bags, Styrofoam parts, etc., could become dangerous toys for children.
- The device should not be handled by children; it is not a toy!

GENERAL NOTES

- Only use original parts provided.
- The product has no replaceable parts.
- Do not attempt to open or repair the product.
- The product is suitable for indoor use.
- **DE:** Eine mehrsprachige Version dieser Anleitung und die Konformitätserklärung finden Sie unter folgendem Link:
- EN: A multilingual version of this manual and the Declaration of Conformity can be found at the following link:
 http://ettgroup.de/product/1451342



TECHNICAL DETAILS

Operating voltage:	12 V
Light color:	neutralwhite
Color temperature:	4200 K
Absorbed power:	3 W
Lifetime:	30000 h
Illumination technology:	12×SMD-2835-LEDs
Length:	300 mm
Width:	25 mm
Height:	9 mm
Energy efficiency class:	This product contains a
	light source of
	Energy effciency class G.
Dimmable:	no
Connection:	via 3.5 mm coax
	(not included)

DISPOSAL INSTRUCTIONS

By separating materials, recycling and disposing of old equipment in this way, you are making an important contribution to protecting our environment. Packaging can be returned to appropriate collection points for free.

WEEE disposal note

According to the European WEEE Directive, electrical and electronic WEEE Directive, electrical and electronic equipment must not be disposed of with household waste. Their components must be recycled or disposed of separately, because toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly.

As a consumer, you are obliged under the Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic equipment free of charge at the end of its service life to the manufacturer, the point of sale or to public collection points set up for this purpose.

Details are regulated by the respective state law. The symbol of the wheeled garbage can on the product, the operating instructions and/or the packaging refers to these regulations.

Made by ETT Distribution GmbH, Schmalbachstraße 16, 38112 Braunschweig www.ett-online.de | Tel. +49 531 58 11 00 | service@ett-online.de Reprinting or reproduction only with expressed permission.