

Item number: 1530723

# Helping Hands McPower „11M-1“

with 4 clamps, very flexible

NE



## TECHNICAL DATA

- 4 adjustable gooseneck arms with clamps
- Metal base with non-slip rubber strips
- With a dry soldering tip cleaner (metal wool)
- With a sponge
- With soldering iron stand
- With rosin

## SAFETY INSTRUCTIONS

- Before operating the device, check for any damage. If there is any damage, please do not operate the device.
- Please be aware that any technical modifications to the device will immediately void its approval.
- Keep the user manual for the device.
- The fumes produced during soldering work are harmful to health in the long term. Therefore, soldering work should only be carried out in well-ventilated rooms or under appropriate extraction.
- Soldering work should only be carried out on de-energized and voltage-free parts.
- For the use of the soldering station in industrial facilities, the relevant legal regulations for accident prevention must be observed.
- Soldering irons reach temperatures of over 160°C. This can cause severe burns!
- The soldering iron should never be immersed in water to cool it down.
- When soldering cables and connectors, ensure that conductive, bare metal parts are protected against contact through suitable measures (with non-flammable material).
- Do not drop the device. It could be damaged upon impact on a hard surface.
- Do not leave packaging materials lying around; plastic films/bags, Styrofoam parts, etc., could become a dangerous toy for children.
- The device is not intended for children; it is not a toy!

## DISPOSAL INSTRUCTIONS

By separating materials, recycling and disposing of old equipment in this way, you are making an important contribution to protecting our environment.

Packaging can be disposed of free of charge at the appropriate collection points:

- Paper in the paper bin
- Plastics in the yellow bag
- Glass in the used glass container

## WEEE disposal note

According to the European WEEE Directive, electrical and electronic WEEE Directive, electrical and electronic equipment must not be disposed of with household waste. Their components must be recycled or disposed of separately, because toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly.

As a consumer, you are obliged under the Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic equipment free of charge at the end of its service life to the manufacturer, the point of sale or to public collection points set up for this purpose.

Details are regulated by the respective state law.

The symbol of the wheeled garbage can on the product, the operating instructions and/or the packaging refers to these regulations.