

# Instruction manual

## Wireless magnetic contact McPower "Comfort" max. 30m, surface mount

### Dear customer

congratulations on the purchase  
your McPower wireless magnetic contact.

With this choice you have chosen a product  
product, which combines appealing design and  
design and technical features.

Please read the following connection and  
carefully and follow these instructions  
and follow them, in order to get the longest and safest  
from your product for as long as possible.  
Please read the operating instructions carefully before  
carefully before using the device.

We wish you much pleasure with your  
new product!



### Features

Practical magnetic contact for switching lights, fans or ventilators.  
The consumer switches on automatically when e.g. a door  
or window is opened.


### Safety instructions

- Keep the operating instructions of the device
- Check the device regularly for damage
- Do not modify the product or accessories
- The product is not suitable for outdoor use.
- Do not short-circuit the connections and the circuits
- Do not use the product unless it is in perfect condition.
- perfect condition. Do not operate a defective
- Check the device for damage before putting it into operation.  
If this is the case, please do not put the device into operation!
- Keep the device away from moisture and humidity.
- Avoid extreme loads such as extreme heat or cold, wetness, microwaves, mechanical pressure and vibrations.
- In case of questions, defects, mechanical damage, and other problems, please contact the dealer or manufacturer.
- Repair and maintenance work on the device may only be carried out by trained personnel!
- The product is not a toy and does not belong in children's hands!
- Do not leave the packaging material carelessly lying around, plastic foils / bags, styrofoam parts, etc.,  
could become a dangerous toy for children.
- This product contains a button cell battery. If the button cell battery is swallowed, it can cause severe internal burns  
and death in as little as 2 hours. Do not swallow the battery, risk of burns.
- Keep new and used batteries out of the reach of children. If the battery compartment cannot be closed securely, stop  
using the product and keep it away from children. If you think batteries may have been swallowed or lodged in any  
part of your body, seek medical attention immediately.

### Technical details:

- On/off switch for the Comfort System
- Duty cycle adjustable: 6s, 15s, 1min or none
- operation: CR2032 battery (included)
- easy teach-in: transmitter and receiver  
connect almost by themselves
- LED function indicator for on/off and teach-in  
function
- frequency: 433,92 MHz
- range up to 30m (in free field)
- automatic alignment of frequencies to avoid  
overlaps
- compatible with all radio receivers of the  
McPower Comfort series
- dimensions base: 35x80x15mm
- dimensions sensor: 10x80x15mm

## **Mounting**



The distance between the two components must not exceed 15mm.

## **Coupling**

Up to ten transmitters can be paired with each receiver socket or module.

To program a socket, press the learn button until the LED starts flashing.  
Press the learn button under the battery cover from the magnetic contact until the LED indicator on the receiver stops flashing and the LED is lit.

## **Decoupling**

Put the receiver into pairing mode (indicator LED flashes). Now press the learn button under the battery cover from the magnetic contact until the LED indicator on the receiver stops flashing and the LED is off.

## **Time setting**

The wireless magnetic contact has 3 selectable time settings (6s,15s,1min) that will turn on a wireless outlet or other receiver for a specific period of time. To select the desired time setting, remove the battery cover and slide the switch to the appropriate position.

If you do not need the time function, set the button to "OFF".

## **Disposal instructions**

According to the European WEEE Directive, electrical and electronic equipment must not be disposed of with household waste. Their components must be recycled or disposed of separately, because toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly. As a consumer, you are obliged under the Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic equipment free of charge at the end of its service life to the manufacturer, the point of sale or to public collection points set up for this purpose. Details are regulated by the respective state law. The symbol on the product, the operating instructions and/or the packaging indicates these regulations. By separating, recycling and disposing of old equipment in this way, you are making an important contribution to protecting our environment.

Packaging can be disposed of free of charge at the appropriate collection points - paper in the paper garbage can, plastics in the yellow bag and glass in the used glass container.